



Class overview today - November 19, 2018

- Lecture: **Advection of the Earth's surface**
 - The advection equation
 - Application: Bedrock river incision
- Exercise 4: **River advection**



Introduction to Quantitative Geology

Advection of the Earth's surface: Fluvial incision and rock uplift

Lecturer: David Whipp
david.whipp@helsinki.fi

19.11.2018




Goals of this lecture

- Introduce the **advection equation**
- Discuss application of the advection equation to **bedrock river erosion**




What is advection?



- Advection involves a lateral translation of some quantity
- For example, the transfer of heat by physical movement of molecules or atoms within a material. A type of convection, mostly applied to heat transfer in solid materials.



What is advection?



- Advection involves a lateral translation of some quantity
- For example, the transfer of heat by physical movement of molecules or atoms within a material. A type of convection, mostly applied to heat transfer in solid materials.



Diffusion equation

$$q = -\rho\kappa \frac{\partial h}{\partial x}$$

$$\frac{\partial h}{\partial t} = -\frac{1}{\rho} \frac{\partial q}{\partial x}$$

- Last week we were introduced to the **diffusion equation**
- Flux (transport of mass or transfer of energy) proportional to a gradient
- Conservation of mass: Any change in flux results in a change in mass/energy



Diffusion equation

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

$$q = -\rho\kappa \frac{\partial h}{\partial x}$$

$$\frac{\partial h}{\partial t} = -\frac{1}{\rho} \frac{\partial q}{\partial x}$$

- Substitute the upper equation on the left into the lower to get the classic **diffusion equation**
- q = sediment flux per unit length
 ρ = bulk sediment density
 κ = sediment diffusivity
 h = elevation
 x = distance from divide
 t = time



Advection and diffusion equations

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- This week we meet the **advection equation**



Advection and diffusion equations

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- This week we meet the **advection equation**
- Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change* in gradient)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$



Advection and diffusion equations

River channel profiles

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$




Fig. 1.7, Pelletier, 2008

- This week we meet the **advection equation**
- Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$



Advection and diffusion equations

River channel profiles

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$




Fig. 1.7, Pelletier, 2008

- This week we meet the **advection equation**
- Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$



Advection and diffusion equations

River channel profiles

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$




Fig. 1.7, Pelletier, 2008


- This week we meet the **advection equation**
- (b) • Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$




Advection and diffusion equations

River channel profiles

Advection



Diffusion



Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- This week we meet the **advection equation**
- Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$


Fig. 1.7, Pelletier, 2008




Advection and diffusion equations

River channel profiles

Advection



(a)



Diffusion

(b)

alluvial channel

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- This week we meet the **advection equation**
- Two key differences:
 - Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)
 - **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$


Fig. 1.7, Pelletier, 2008




Advection and diffusion equations

River channel profiles

Advection



(a)



(b)

Diffusion

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- This week we meet the **advection equation**

- Two key differences:

- Change in mass/energy with time proportional to gradient, rather than curvature (or *change in gradient*)

- **Advection coefficient** c has units of $[L/T]$, rather than $[L^2/T]$



Fig. 1.7, Pelletier, 2008



Advection and diffusion equations

River channel profiles

Advection



Diffusion

Diffusion

$$\frac{\partial h}{\partial t} = -\kappa \frac{\partial^2 h}{\partial x^2}$$

Advection


$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- **Diffusion:** Rate of erosion depends on change in hillslope gradient (curvature)
- **Advection:** Rate of erosion is directly proportional to hillslope gradient
- Also, no conservation of mass (deposition)

Fig. 1.7, Pelletier, 2008



Advection at a constant rate c



- Surface elevation changes in direct proportion to surface slope
- Result is lateral propagation of the topography or river channel profile
- Although this is interesting, it is not that common in nature



Advection of the Earth's surface: An example


Athabasca Falls, Jasper National Park, Canada



- **Bedrock river erosion**
- Purely an advection problem with a spatially variable advection coefficient

Bedrock river erosion


Drainage basin



- Not much bedrock being eroded here...

Bedrock river erosion

Drainage basin



- Rapid bedrock incision has formed a steep gorge in this case



River erosion as an advection process




Fig. 1.7, Pelletier, 2008

- With a **constant advection coefficient c** , we predict lateral migration of the river profile at a constant rate (c)



River erosion as an advection process




Fig. 1.7, Pelletier, 2008

- With a **constant advection coefficient c** , we predict lateral migration of the river profile at a constant rate (c)
- **Do you think this works in real (bedrock) rivers?**



River erosion as an advection process





Fig. 1.7, Pelletier, 2008


- With a **constant advection coefficient c** , we predict lateral migration of the river profile at a constant rate (c)
- **Do you think this works in real (bedrock) rivers?**
- **What might affect the rate of lateral migration?**

What affects the efficiency of river erosion?



- The **amount of water flowing** in the river (**discharge**) and sediment
- The **slope** of the river channel
- The **strength of the underlying bedrock**

What affects the efficiency of river erosion?



- The **amount of water flowing** in the river (**discharge**) and sediment
- The **slope** of the river channel
- The **strength of the underlying bedrock**
- **Are these constant?**



Stream-power model of river incision

$$\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}$$

- Rather than being constant, the rate of lateral advection in river systems is spatially variable

$$\frac{\partial h}{\partial t} = \frac{k_f}{w} Q \frac{\partial h}{\partial x}$$

where k_f is a material property of the bedrock (erodibility), w is the channel width, and Q is discharge



Stream-power model of river incision

$$\cancel{\frac{\partial h}{\partial t} = c \frac{\partial h}{\partial x}}$$

- Rather than being constant, the rate of lateral advection in river systems is spatially variable

$$\frac{\partial h}{\partial t} = \frac{k_f}{w} Q \frac{\partial h}{\partial x}$$

where k_f is a material property of the bedrock (erodibility), w is the channel width, and Q is discharge

- This is known as the **stream-power erosion model**



Stream-power model of river incision

- If we assume precipitation is uniform in the drainage basin, discharge Q will scale with drainage basin area, so we can modify our equation to read

$$\frac{\partial h}{\partial t} = \frac{k_f}{w} Q \frac{\partial h}{\partial x} \longrightarrow \frac{\partial h}{\partial t} = K A^m S^n$$


where K is an erosional efficiency factor (accounts for lithology, climate, channel geometry, sediment supply, etc. (!)), A is upstream drainage area, S is channel slope, and m and n are area and slope exponents

- If we assume the drainage basin area increases with distance from the drainage divide x , we can replace the area with an estimate $A = x^{5/3}$



Test your might

$$\frac{\partial h}{\partial t} = U - K A^m S^n$$




- Based on our **stream-power erosion** equation, what general form would a channel profile take?
- If we assume we have reached a steady state ($\partial h/\partial t = 0$) and $n = 1$, erosion must balance uplift U everywhere
- If we further assume precipitation is constant, bedrock erodibility is constant and $A = x^{5/3}$, **how would the channel steepness vary as you move downstream from the divide?**
- Think about how S would change as x increases



Evolution of a channel profile

Fig. 3.23, Allen, 1997



- A few stream-power erosion observations:
 - Stream power increases downstream as the discharge grows
 - Steeper slopes occur upstream where the discharge is low
 - Incision migrates upstream until a balance is attained between erosion and uplift



Recap

- **What is the main difference between the advection and diffusion equations?**
- **What is special about the stream power erosion model compared to the general advection equation?**



Recap

- What is the main difference between the advection and diffusion equations?
- **What is special about the stream power erosion model compared to the general advection equation?**



References

Allen, P.A. (1997). *Earth Surface Processes* (First edition.). Wiley-Blackwell.

Pelletier, J. D. (2008). *Quantitative modeling of earth surface processes* (Vol. 304). Cambridge University Press.